

When facing the head, add a 0.015" (0.4 mm) counterbore, 0.015" (0.4 mm) deep (as shown). This will minimize arcing and binding of the pin in the event the part being welded has a sharp edge or burr around the hole.

